

Cold weather storage




A GUIDE TO LOOKING AFTER YOUR CABIN WHILST NOT IN USE.

Heating & hot water systems

1. Run the heating system at least 1 hour with the heating on full. Confirm heater is running and all heaters are producing heat.
2. Plug the cabin into the electrical mains and leave the boiler on. This will prevent internal damage.





Important:
Ensure there is water in the system when doing this

General

1. Isolate incoming water pressure. Press all taps, shower buttons and flush toilets to drain the system.
2. Turn the drain valve or pressure relief valves to remove any water in the system. (2 valves - above and below the boiler)
3. Lubricate your door mechanisms. Use only a silicone, or P.T.F.E. based lubricant spray which will leave a long lasting and protective film on moving parts.
4. Ensure the door cylinder operates correctly and check any turns are fixed to the cylinder, tightly – tighten the thumb turn grub screw if needed.
5. Clean the cabin fully, this will preserve the quality of the product.

